Installation Instructions

Refrigeration Packages

INSTALLATION

- 1. Insure proper ventilation. In fully recessed drinking fountains be sure condenser faces louver panel and is within 1/2" (13 mm) of louver panel when panel is in place.
- 2. Water inlet is 3/8" (10 mm) O.D. unplated tube. Contractor to supply connections as required.
- **3. Connecting lines to be made of unplated copper.** Thoroughly flush all lines to remove all foreign matter before connecting to cooler.
- **4. Connect cooler to building supply** with a shut-off valve and install a 3/8" (10 mm) unplated water line between the valve and cooler. Remove burrs from outside of water line. Insert water line into bulkhead union until it reaches a positive stop, approximately 3/4" (19 mm).

NOTE: DO NOT SOLDER TUBES INSERTED INTO THE STRAINER AS DAMAGE TO THE O-RINGS MAY RESULT.

5. Electrical: Make sure power supply is identical in voltage, cycle, and phase to that specified on cooler serial plate. Never wire the compressor directly to the power supply.

IMPORTANT! INSTALLER PLEASE NOTE:

The grounding of electrical equipment such as telephone, computers, etc., to water lines is a common procedure. This grounding may be in the building, or may occur away from the building. This grounding can cause electrical feedback into a water chiller, creating an electrolysis which causes a metallic taste or an increase in the metal content of the water. This condition is avoidable by using the proper materials indicated below. Drain fittings which are provided by the installer should be plastic to electrically isolate the chiller from the building plumbing system.

START-UP

- 1. Open supply line valve.
- 2. Purge all air from all water lines by operating bubbler valve of fountain to which cooler is connected. A steady stream flow assures that all air is removed.
- 3. Rotate fan blade to assure proper clearance and free action.
- 4. Connect to proper electrical power.


TROUBLE SHOOTING & MAINTENANCE

Temperature Control: Factory-set for 50°F water (± 5°) under normal conditions. For colder water, adjust screw on item no. 5.

Ventilation: Cabinet louvers and condenser fins should be periodically cleaned with a brush, air hose, or vacuum cleaner. Excess dirt or poor ventilation can cause no cold water and compressor cycling on the overload protector.

Lubrication: Motors are lifetime lubricated.

Actuation of Quick Connect Water Fittings: Cooler is provided with lead-free connectors which utilize an o-ring seal. To remove tubing from the fittings, relieve water pressure, push in on gray collar while pulling on the tubing. To insert tubing, push tube straight into fitting until it reaches a positive stop, approximately 3/4".



ECP8*1A, ECP8*2A, ECP8*3A

PARTS LIST			
ITEM NO. PARTNO.		DESCRIPTION	
1	66505C	EVAPORATOR ASSY	
2	28339C	SHROUD-FAN	
3	66531C	HEAT EXCHANGER	
4	55996C	STRAINER	
5	31513C	COLD CONTROL	
6*	35947C	COMPRESSOR SERV. PAK	
7	31039C	OVERLOAD/RELAY ASSY	
8	35768C	COVER RELAY	
9	35935C	CAPACITOR - RUN	
10	19037000	CLIP-COMPMTG	
11 101516143550		STUD-COMPMTG	
12 100806740570		GROMMET - COMP MTG	
13 20282C		BRACKET - FAN MTG	
14	31490C	FAN MOTOR	
15	70018C	NUT	
16	30664C	FAN BLADE	
17	66202C	DRIER	
18	66305C	CONDENSER	
19	31504C	POWER CORD	

220/240 - 50/60HZ		
ITEM NO.	PARTNO.	DESCRIPTION
3	66236C	HEAT EXCHANGER (ECP2/3)
6*	36085C	COMP SERV. PAK (ECP-2)
	35842C	COMP SERV. PAK (ECP-3)
7	36195C	OVERLOAD (ECP-2)
	36050C	RELAY (ECP2)
14	31430C	FAN MOTOR (ECP-2)
	31431C	FAN MOTOR (ECP-3)
19	31506C	POWER CORD (ECP2/3)

*INCLUDES RELAY & OVERLOAD. IF UNDER WARRANTY REPLACE WITH SAME COMPRESSOR USED IN ORIGINAL ASSEMBLY.

NOTE: ALL CORRESPONDENCE PERTAINING TO ANY OF THE ABOVE WATER COOLERS OR ORDERS FOR REPAIR PARTS MUST INCLUDE MODEL NO. AND SERIAL NO. OF COOLER, NAME AND PART NO. OF REPLACEMENT PART.

