

INSTRUCTION SHEET - 96725C VANDAL RESISTANT KIT

THIS KIT CONTAINS A SUFFICIENT QUANTITY OF TAMPER-RESISTANT SCREWS TO MODIFY YOUR WATER COOLER.

INSTRUCTIONS FOR MODIFICATIONS:

- 1. REMOVE EXTERIOR SCREWS ONE AT A TIME AND REPLACE WITH A TAMPER-RESISTANT SCREW OF THE SAME SIZE AND LENGTH. SPECIAL DRIVE BITS ARE PROVIDED FOR THE TAMPER-RESISTANT SCREWS.

CAUTION: DO NOT REMOVE ALL EXTERIOR SCREWS BEFORE REPLACING THEM WITH TAMPER-RESISTANT SCREWS.

2. KIT CONSISTS OF:

ITEM	QTY.	PART NO.	DESCRIPTION
1	1	70023C	SET SCREW #6-32 X .12
2	6	75570C	SCREW - #10 X .50
3	1	40047C	NUT - COVER CP VP
NS	1	75520C	BIT - PINNED TORX

