

Bubbler Replacement Instructions

These instructions are to provide direction for the replacement of the Flex-Guard Bubbler Assembly. The assembly may contain one of two style bubblers, brass with a seperable flex-guard or plastic with a co-molded flex guard. Unless otherwise stated, these instructions apply to either design.

1. Remove front panel to gain access to the bubbler from under the basin.
2. **PLASTIC** - Use a 1-1/8 inch open end wrench to remove the bubbler nut from underneath. Push in on the fitting collet and pull tubing out to remove existing bubbler, see Figure A.
BRASS - Loosen nut fully from underneath basin. Unscrew the bubbler from above and remove. Cut tubing approximately five inches below the nipple. Solder extension tubing onto outlet water line. The expanded end of the tubing may be cut off if required. The free end of the tubing must be the 1/4 in. size.
3. Slide the bubbler nut onto the tubing, with the flat side facing the basin. Push the free end of the tubing 1-2 inches through the basin hole.
4. Loosely position the chrome pedestal around the bubbler housing. Insert the tubing into the fitting at the bottom of the housing. Gently push the tubing in until it reaches a positive stop, approximately 3/4 inch.
5. Keeping the pedestal in position (pushed forward) tighten the nut from underneath the basin.
6. Re-assemble front panel.

Figure A

OPERATION OF QUICK CONNECT FITTINGS

